

# Hanging with the UrbanTrapeze In-Line Ceiling-Sign Connector Kit

- A. Insert one length of cable into a Sign Panel Connector so the ball nests inside the drum. Repeat with second length of cable. **1**
- B. Attach each Sign Panel Connector to the top edge of the sign. Use the Hex Key to tighten the set screw for a secure connection. **2**
- C. Attach the Cable Connectors to a standard,  $1\frac{5}{16}$ -inch wide, drop ceiling. Twist each connector onto the T-bar at the same distance as the Sign Panel Connectors on the sign. **3**
- D. Insert the free ends of the steel cables into the Ceiling Cable Connectors. Push the button on the bottom to release the brake when inserting or adjusting the cable. Release the button to lock the cable in place. Adjust the height of the sign in relation to the floor, and make it level. **4**  
Trim the excess cable at the exit hole. **5**

